

Issued Date : Feb.25th,2017 Camera Version: S6X70225

Upgrade Method :

1. Unzip the download WinRAR file and Copy the file named WingSland.bin to the root directory of Micro SD card.
2. Ensure the aircraft is power off, then insert the Micro SD card to the Camera slot.
3. Power on the aircraft, the camera firmware will upgrade automatically. The upgrade process takes about 1 minute.
4. Connect the mobile device and launch the APP. Check if it is the latest camera version.

Note: Make sure the battery is fully charged during the upgrade.

Technical Support: 866-944-8840

After-Sales Tel: support@szsungreen.com

